










USB 3&4  
J9A1



MONO OUT

HEAD  
PHONE  
OUT

A G P

P C I


P C I

P C I

P C I




A T X P O W E R



JP19


INTERRUPT  
MODE

JP2




Primary

1



Secondary


1



J3 RAM



J4 RAM



\*ALL EXCEPT  
BLUE LEDES 100F

POWER LED

Power  
switch